


OPERATIONS MANUAL

IM-5P UNDERPINNER



Tilting Stand



INDEX

<u>1. GENERAL INFORMATION</u>	3
1.1 Introduction	3
1.2 Main Components	3
1.3 Optional Accessories	3
1.4 Technical Specifications.....	4
1.5 Warranty	5
1.6 Authorized Service	5
<u>2. SAFETY</u>	5
2.1 General Warnings	5
2.2 To Reduce the Risk of Injury.....	6
<u>3. HANDLING AND STORAGE</u>	7
3.1 Handling	7
3.2 Storage.....	7
<u>4. UNPACKING</u>	7
<u>5. MACHINE DESCRIPTION</u>	7
5.1 Working Principle	7
5.2 Nailing Head	8
5.3 Using the Clamps.....	8
5.4 Selecting the v-nails	8
5.5 Loading the magazine with v-nails	8
5.6 Air Pressure Regulator for the front and upper clamps	9
5.7 Height adjustments for the mechanical upper clamps.....	9
5.8 Slight adjustments for the mechanical clamps.....	10
5.9 Vertical hydraulic clamps adjustments	11
5.9.1 Adjustment for the front clamp.....	11
5.9.2 Fixed fence position	12
5.9.3 Fence adjustment.....	12
5.9.4 Perpendicularity adjustment	12
5.9.5 Fence angle adjustment	12
<u>6. OPERATION</u>	13
6.1 Positioning the joystick.....	13
<u>7. MAINTENANCE</u>	14
7.1 Every 10 working hours	14
7.2 Every week	14
7.3 How to remove the nailing head and clean it	15
7.4 How to assembled the counterweight balancer	16
7.5 How to change the nail pusher	17
7.6 How to change the joystick from the right to the left.....	18
7.7 Air Filter lubricator and oil lubricator	19
7.8 Oil level on lower edge of oil glass	19
7.9 Air filter lubricator	20
<u>8.0 PART LIST</u>	21
<u>9.0 EXPLODED VIEW</u>	23
<u>10.0 PNEUMATIC SCHEME</u>	27

1.GENERAL INFORMATION

1.1 INTRODUCTION

Congratulations on your purchase of the IM-5P! It benefits from our long of experience acquired during years of designing frame assembly machines for the picture framing industry.

The IM-5P developed by Inmes is a pneumatic frame assembly machine which is designed to be operated on a work table or a tilting stand, in front of the machine or behind it. This versatile underpinner can be supplied with double mechanical clamps or double hydraulic clamps allowing you to provide proper support for wide frames with complex profiles.

1.2 MAIN COMPONENTS






The main components including with the machine are:

Front Clamp
Allen Wrenches
Tilting Stand
Instructions Manual
Counterweight Balancer
Leveling Bolts

1.3 OPTIONAL ACCESSORIES

Double Mechanical Clamps	Part No. INM01010334
Double Hydraulic Clamps	Part No. INM01010335
Extension Wings	Part No. INM01010133

1.4 TECHNICAL SPECIFICATIONS



1.5 WARRANTY

INMES products are built to have long durability and are tested one by one before leaving the factory. The IM-5P is covered by one (1) year warranty to be free from defects in parts and manufacturing defects only, providing the machine has been under normal use. Labor is not included with the warranty, the return of the equipment is fully at the purchaser's expenses. The repair will be effected where you have bought the machine and the freight of the shipment will be entirely charged to the customer.

The warranty does not cover damages caused by inappropriate use of the machine, or by use not in conformity with the terms of this instructions described in this owner's manual.

The warranty is not valid in case of unauthorized modifications or because of accidental damages effected by unqualified personnel.

1.6 AUTHORIZED SERVICES

INMES is represented by numerous and prepared organizations in every country that we sell. Please feel free to contact us at +55 (48) 3658-2064 export_dept@inmes.com.br to be informed concerning the Closest Authorized Dealer Service.

2. SAFETY

Always remember that careless fraction of a second is enough to cause a severe injury.

2.1 GENERAL WARNINGS

For the operator's safety and durability of your equipment the instruction manual must be followed with great care when installing and operating your machine, staying alert and learn how to use the IM-5P.



If the safety instruction is not followed the operator will be seriously injured.



It means if the safety instruction is not followed the operator could be seriously injured.



Safety instruction if not carried out with care might injury the operator.

WARNING

- Read the Instruction Manual before operating the equipment;
- Do not remove or change the warning adhesive signs;
- Wear adequate clothing to avoid clothes that could get stuck in the moving parts;
- Long hair has to be tied up;
- Keep hands away from the working area;
- Disconnect air pressure supplying during any maintenance intervention;
- Keep the feet away from the foot pedal during machine regulation;
- The machine must be mounted on a flat surface in an appropriate work area, well lighted;
- The user guarantee the machine is operated only by trained operators;
- The user must prevent access to the machine by non-authorized people;
- In order to obtain high performance of the machine, make sure that you read the instruction manual;
- Keep children and visitors away

2.2 TO REDUCE THE RISK OF INJURY

- Never place your hands under the vertical clamps;
- Never place your hands in front of the front clamp;
- Hold the profile firmly against to the fence with your hands outside of the clamping area;
- Before using the machine be sure that no objects have been left on the working table
- If any part is missing, bent or broken in anyway, do not use the equipment;
- Never use your machine if you observe something which can cause an accident or damage the equipment;
- Keep work area around the machine clean;
- Keep visitors and children away when using;

Note: Always remember that a careless fraction of a second is enough to cause a severe injury.

3. HANDLING AND STORAGE

3.1 HANDLING

Two people are required to locate the machine. The machine has to be shipped in a safe way to avoid any damage. Mount it securely on a proper floor. The machine has to be shipped like positioned for installation.

3.2 STORAGE

The machine must be stored with cautions, as per information below:

- Store the machine indoors;
- Protect the machines from accidental impacts;
- Protect the machine from humidity;
- Avoid the machine to come in contact with corrosive materials;

4. UNPACKING

Unpack the machine and verify all components to make sure the following parts are included:

- c) IM-5P Underpinner
- d) Front clamp
- e) Wrenches
- f) Instructions Manual

- g) Optional Accessories:
- h) Double upper Hydraulic clamps or Mechanical clamps
- i) Extension Arms

5. MACHINE DESCRIPTIONS AND ADJUSTMENTS

Before using the machine it is necessary to make some adjustments according to the profile moulding to join.

5.1 WORKING PRINCIPLE

The Inmes frame assembling machine IM-5P is versatile and extremely easy to use. It can be supplied with double mechanical clamps or double hydraulic clamps allowing the operator to provide proper support for wide frames. It can join with absolute precision any kind of moulding by means of special steel v-nails. The machine can be supplied in either tilting or closet stand model.

5.2 NAILING HEAD

The nailing head is moved from one position to the next position by sliding the joystick, while the moulding remains clamped and locked in one position.

5.3 USING THE CLAMPS

Use the foot pedal to immediately activate the front clamp followed by the upper clamps, while the Joystick activates the nail pusher to insert the nail.

5.4 SELECTING THE V-NAIL

The Inmes nails are specially designed to hold the frames pieces firmly together creating a tight joint. There are 5 different sizes of 5-7-10-12-15mm, as shown in fig 1. Each nail size is available for either hardwood or softwood. For maximum strength, place two or more nails along the frame.




Fig. 1

5.5 LOADING AND CHANGING V-NAIL INTO THE MAGAZINE

There is a quick change nail device located at the rear of the machine for changing the nail, just rotate the knob clockwise and choose the nail size showed by the know arrow fig. 2. And then pull on the spring loaded cable as show in fig. 3 arrow "B" and insert one v-nail stick into the magazine fig. 4 arrow "C", make sure the "V" of the v-nail is pointing in the direction indicated by the arrow "A" in fig. 3. Finally release the spring loaded cable.



Fig. 2




Fig. 3



Fig. 4

5.6 AIR PRESSURE REGULATOR FOR FRONT AND UPPER CLAMPS

The working pressure must be adjusted to the hardness of the moulding to be assembled. The pressure regulation allows changing the clamping pressure of moulding to be assembled. When the working pressure is too high this may cause a poor joining and the moulding crushing. When the working pressure is too low this may cause incomplete insertion of V-nail into the frame.

Both the front and upper clamps have independent air pressure regulator, as shown fig. 5 while the nail insertion pressure is adjusted by the main air pressure regulator, fig. 6. Attach the compressed air source to the machine with appropriate “quick disconnect fitting”. The source should be filtered and lubricated and not exceed 6 BAR (85 PSI). Then, first set the main air pressure regulator fig 6 at 6 BAR by turning it clockwise to increase the pressure and counterclockwise to decrease the pressure and follow the same procedure to set the front and upper clamps air pressure regulator as shown fig. 6 at 6 BAR.




Fig. 5



Fig. 6

5.7 HEIGHT ADJUSTMENTS FOR THE MECHANICAL UPPER CLAMPS

To perform this adjustment remove each quick pins fig 7 “J”, and raise both cylinders, and then place two pieces of moulding against the fences, now push up the quick locks fig. 8 “D” and slide both cylinders so they are positioned above the frame corner as suggested in fig 7, be sure the quick locks are tightened to prevent slippage. Set the pads at 3/8” (10mm) above the frame.



Fig. 7




Fig. 8

IMPORTANT

If a small frame is being joined, remove the “quick pin” and take one of the clamps out.

5.8 SLIGHTLY ADJUSTMENT FOR THE MECHANICAL CLAMPS



Fig. 9

In case you need to slightly adjust the height of the cylinders above the frame, the mechanical clamps offer a device that you can move the pads down till about $\frac{3}{4}$ " (19mm) to the top of the moulding, by turning anticlockwise the knobs of each pad as shown in fig 9.

5.9 VERTICAL HYDRAULIC CLAMPS ADJUSTMENT

Instead of using the two mechanical clamps a double hydraulic clamps can be mounted on the IM-5P. The Hydraulic clamps can be useful when changing frequently the profiles or joining profiles that have complicated shapes. In fact thanks to the oil circuit the hydraulic clamps descend and clamp the top of the moulding self-adjusting their vertical position. In order to adjust the hydraulic clamps use the same procedure describe above on item **5.7**




Fig.10

If a small frame is being joined, slide the rear clamp out of position and close the valve fig 10 (L) on top of the rear cylinder. Position the other cylinder pad over the corner of the frame.

5.9.1 ADJUSTMENT FOR THE FRONT CLAMP

The front clamp has a series of holes in the flat bar fig 11. Lift the bar to take it out of its initial position and make it move forward and backward. To lock the bar it is sufficient to insert it into the proper peg located in the middle of the guide channel. Proceed as follow to position the front clamp properly:

- Remove the bar from the peg (lifting it by about 10-15mm) and move it forward up to reach the moulding to be assembled, as shown in fig. 12.
- Lower the bar to allow the insertion of tracking screw and the locking in the next position.
- Place the front clamp at 3/8" (10mm) in front of the frame rabbet.



Fig. 11



Fig. 12

5.9.2 FIXED FENCE POSITION

The IM-5P is equipped with a fixed fence at 90°. The fence and the moulding remains clamped and the “nailing head” is moved from one position to the next position by sliding the joy-stick.

5.9.3 FENCE ADJUSTMENT


The IM-5P underpinner is equipped with adjustable fences in order to obtain always the best results, even with twist mouldings.

5.9.4 PERPENDICULARITY ADJUSTMENT

This operation can be performed by turning clockwise or anticlockwise the proper knobs, as show in fig 13, knobs “A” and “B” it is very useful in those cases when the base of the moulding is not perfectly perpendicular compared with the part of the moulding that leans against the fence. The adjustable fence can be tilted $\pm 2^\circ$.

Before joining the moulding follow this

procedure:



- a. Place the two legs of the moulding against the adjustable fence and set the vertical clamp so that, when pedal is depressed, they can hold the moulding properly.
- b. Press the pedal and check the quality of the joint. In case the joint is not good, release the pedal and adjust the perpendicularity of each fence by turning the knobs “A” and “B” and repeat the operation over described joint.

Fig. 13

5.9.5 FENCE ANGLE ADJUSTMENT

If during the test above, the corner of the frame remains open forward or backward, it is possible to adjust the fence angle of about 1° . Rotate clockwise or anticlockwise the knob of the left fence in fig 13 “C” till the right adjustment is founded. Adjust only left fence. Do not move right fence, it is possible to loose the exact position.

6. IM-5P OPERATION

6.1 POSITIONING THE JOYSTICK

To perform the joining process follows here under procedure:

- Place one of the two moulding legs in position against the fence and position the joy stick **F** so the first nail will be inserted about 3/16" (5mm) from the rabbet. Loosen stops **E** slide it against the joy stick and tighten. This becomes the rear stop. Slide the joy stick **F** toward the front to locate the second nail about 3/16" (5mm) from the frame corner. Loosen and slide the stop **E** against the joy stick **F** and tighten the stops, this becomes the front stop;
- Slide the joy stick **F** to the rear stop for the insertion of the first nail. Place both frame pieces against the fence.
- Set the front clamp **H** in place about 3/8" (10mm) from the rabbet of the frame;




Fig.14

the frame is higher near the corner, you can insert another v-nail at this same location which stacks two nails one on top of the other. If the frame is wide you can move the joy stick **F** to ONE or more intermediary positions, push the fire button **G** **just half way down** which will lock the joy stick **F** in place and then push the fire button **G** full down to insert the nail in the third position

- Adjust the vertical clamps height and position **I**;
- Depress the foot pedal full down and the front clamp will operate immediately followed by the upper clamps, continue to hold the foot pedal down and push the fire button **G** and the first nail will be inserted. Slide the joy stick **F** to the front against its stop and push the fire button **G** to insert the second nail. Since

7. MAINTENANCE

ATTENTION

In order to avoid danger before performing any of the operations described below the machine must be absolutely disconnected from air pressure source!

This machine will provide years of quality performance if maintained carefully. For operator safety before cleaning, lubricating and maintenance remove the plug from air source to avoid unexpected start-up.

Cleanliness and care guarantee not only a longer life time of the machine, but also less risks to operators. So we advise to keep the machine clean and lubricate weekly.

The most important maintenance requirement is cleanliness. Use a brush or clean cloth to wipe the table surface, shafts and pads.

If glue accumulates on the nailing head fig (xx), wipe it off before it dries, otherwise, it will have to be scraped off or removed with the solvent recommended by the glue manufacturer. Be sure glue does not dry on the upper clamp pads because it will damage the top of a frame.

7.1 EVERY 10 WORKING HOURS:

- a. Check compressed air condensation in the filter glass;
- b. Blow air pressure to eliminate pieces of staples or wood dust that can go inside the movable parts of the machine;

7.2 EVERY WEEK:



Fig. 15

- a. Check oil level inside the filter lubricator fig 15;
- b. In case oil is needed add for pneumatic circuits low density;

7.3 HOW TO REMOVE THE NAILING HEAD AND CLEAN IT




Fig. 16




Fig. 17

For operator safety, always disconnect the air source before cleaning, lubricating or performing any maintenance.

- a) Using the 5mm Allen key, loosen the locking screws A and B of the nailing head, fig 16. Then loosen the locking screws C and D of the magazine, fig 17.
- b) Then using your hands pull back the magazine a little bit fig 18. Now you are able to remove the nailing head and accomplish your regular maintenance, as show in fig 19.



Fig. 18



Fig. 19

- c) Once you have the nailing head out of the machine, place it on a flat surface with a 4mm Allen wrench, loosen and remove the four screws, as shown in figs. 20/21



Fig. 20



Fig. 21

- d) Clean the inside of the nailing head using a cloth and a drop or two of pneumatic oil. After cleaning, wipe down the nailing head with a dry cloth. Then put one drop of pneumatic oil on the inside of the nailing head.
- e) Before mounting the nailing head, we suggest you use a flat surface (like a mirror) in order to give a precise alignment of the two parts. If the top and sides are not in precise alignment, it will not work properly, as shown in fig 22.
- f) When attaching the nailing head over the drive pin make sure to place it according to fig 23



Fig.22



Fig. 23

- g) Place the nailing head on its original position and using the 5mm Allen key tighten the locking screws A and B of the nailing head, fig 16. Then place the magazine on its original position fixed to the nailing head and tighten the locking screws C and D of the magazine, fig 17;

7.4 HOW TO ASSEMBLE THE COUNTERWEIGHT BALANCER

For operator safety, always disconnect the air source before cleaning, lubricating or performing any maintenance.

The IM-5P underpinner is designed to be operated on a closet stand or a tilting stand. The counterweight balancer spring is provide with the machine for using just with the tilting stand in order to set the weight of the hammer block assembly when the machine is tilted. Proceed as follow to attach the counterweight balance on the machine. See fig 24 how to assemble the spring.



Fig.24

Tilt the working table by loosen the knobs on the left and right sides of the stand ;
Then attach one end of the spring over the bolt as shown in fig. 24 and the other end of the spring attaches to another bolt located beside the cylinder.

7.5 HOW TO CHANGE THE NAIL PUSHER

For operator safety, always disconnect the air source before cleaning, lubricating or performing any maintenance.

In order to remove the nail pusher, follow these procedures:

- Tilt the working table
- Disconnect the air hose source fig. 25 arrow "A" and loosen the two locking screws B;
- Now using a 6mm Allen key, loosen the (4) four locking screws and remove the cylinder lid, as show in fig 26/27 ;
- Then using a pair of pliers remove the complete device for the nail pusher cylinder, as show in fig 28;
- Once you have the nail pusher out, add a small amount of pneumatic oil around the new rubber gasket;
- Carefully place the new one back inside the cylinder fig 28, making sure the top edge of the rubber gasket is inside the cylinder before pushing, if not, damage may occur to the rubber gasket. Also, make sure the nail pusher is in the nailing head;
- Once you have the complete nail pusher device into the cylinder, reassemble the cylinder lid with the 6mm Allen key and tighten the (4) four screws as shown in fig 26. Then tighten the other two screws B and C as shown in fig 25;
- Finally attach the air hose to the cylinder, and with the nails out, make a few tests before you start production.



Fig. 25



Fig. 26



Fig. 27



Fig. 28

7.6 HOW TO CHANGE THE JOYSTICK FROM THE RIGHT TO THE LEFT.

CAUTION

For operator safety, always disconnect the air source before cleaning, lubricating or performing any maintenance. In order to change position for the joy stick, follow these procedures:

- Disconnect the air source;
- There are 4 hoses connected to two valves, disconnect and mark them before changing the side of the joy stick
- Using the 3mm Allen key loosen the locking screws of the joystick handle fig 29 and take the housing out as shown in fig 30, then pull up and rotate the joystick arm in order to take it out;
- Then under the working table there is a support bracket attached to the cylinder, using the 5mm Allen key loosen the two locking screws; as shown in fig. 31;
- Once you have done this procedure you are ready to move the joystick to the opposite side.
- Pull bracket down, and then rotate to the other side.
- Unscrew and move locking levers to other side.
- Reassemble



Fig.29



Fig.30



Fig.31

7.7 AIR FILTER LUBRICATOR AND OIL LUBRICATOR

CAUTION

For operator safety, always disconnect the air source before cleaning, lubricating or performing any maintenance.

7.8 OIL LEVEL ON LOWER EDGE OF OIL GLASS

INMES products are constructed to have a long duration and are tested one by one. However, we ship the machines without oil inside the lubricator glass and it is necessary to fill the lubricator glass to obtain good performance of the equipment. The number of drops of pneumatic oil is adjusted at the factory. It is usually not necessary to adjust afterwards. We recommend that the customer verify that after every 25 to 30 actions of the foot pedal, ONE drop should fall. In order to refill the lubricator glass, proceed as follows:

- Shut air supply, fig 32 "A"
- Unscrew the lubricator glass by turning clockwise direction, fig 32 "B", fig.33.
- Fill the lubricator glass with pneumatic oil, a little more than half glass
- Screw the lubricator glass back on making sure the O-ring is sitting correctly in the housing




Fig. 32



Fig. 33

7.9 AIR FILTER LUBRICATOR

CAUTION

For operator safety, always disconnect the air source before cleaning, lubricating or performing any maintenance.

When the compressed air leaves the air source it comes with water, impurity and dust, so the function of the filter lubricator is to filter the compressed air eliminating water and collecting dust and other impurities inside the filter glass. Every source of compressed air differs from one another, so consecutively, quantity of water and impurities are collected. That is why we strongly recommend that the customer verify daily, the oil level and water inside the air filter lubricator. When it is necessary to empty the water inside the filter glass, (it is not necessary to shut air supply) just loosen the drain located under the bottom of the filter, as shown in fig 34 “A”. However, we recommend cleaning the filter lubricator located inside the filter glass at least once a week. In order to clean it up, proceed as follow:

- Shut air supply,
- Unscrew the filter glass by turning clockwise direction,
- Unscrew the filter (black piece) as shown in fig 35;
- Then unscrew the black piece showed in fig 35, inside this part you will find a white piece fig 36, then clean inside both parts using air
- Once these procedures are done then screw filter back to its original position;
- Screw the lubricator glass back on making sure the O-ring is sitting correctly in the housing



Fig. 34



Fig. 35



Fig. 36


8-PART LIST IM-5P

Code	Descriptions	Code	Descriptions
INM01010334	Mechanical clamps IM-5P	INM04070290	Connection 6MM
INM01010335	Hydraulic clamps IM-5P	INM04070291	Male connector 1/4POLX5/16MM
INM03010038	Allen screw M5 (Z)	INM04070292	Manometer FMA 50-1/4
INM03010213	Tilting stand IM-5P	INM04070293	Air filter lubricator MINI 1/4"
INM03010225	Support counterweight balancer IM-5 (Z)	INM04070294	Oil lubricator LOE-D-MINI 1/4"
INM03010229	Longer guide shaft IM-5	INM04070295	Activator R-3-M5
INM03010230	Shorter guide shaft IM-5	INM04070297	Air pressure regulator LR-1/8-F
INM03010232	Support for the guide shaft IM-5P	INM04070298	Valve VL-5/2 VIAS-1/8
INM03010238	Magazine base IM-5P (Z)	INM04070299	Muffler 1/8POL
INM03010240	Pin IM-5P (Z)	INM04080004	Allen screw Internal M3x10MM DIN 912
INM03010242	Nail definer IM-5P (Z)	INM04080007	Allen screw Internal M4X10MM DIN 912
INM03010245	Shaft IM-5	INM04080009	Allen screw Internal M4X20MM DIN 912
INM03010247	Washer (Z)	INM04080012	Allen screw Internal M5x8MM
INM03010249	Washer for the knob IM-5P (Z)	INM04080015	Allen screw Internal M5X25MM DIN 912
INM03010259	Cylinder support IM-5P (Z)	INM04080016	Allen screw Internal M6X16MM DIN 912
INM03010261	Guide IM-5P (Z)	INM04080019	Allen screw Internal M6X25MM DIN 912
INM03010263	Guide peg IM-5P (Z)	INM04080020	Allen screw Internal M6X30MM DIN 912
INM03010265	Movement bar IM-5P (Z)	INM04080021	Allen screw Internal M6X35MM DIN 912
INM03010266	Activator for the valve IM-5	INM04080025	Allen screw Internal M8X16MM DIN 912
INM03010270	Shaft Housing IM-5	INM04080026	Allen screw Internal M8X20MM DIN 912
INM03010274	Support for the activator SU IM-5P (Z)	INM04080029	Allen screw Internal M8x35MM
INM03010283	Upper support IM-5P (Z)	INM04080031	Allen screw Internal M8X45MM DIN 912
INM03010285	Washer IM-5P (Z)	INM04080038	Allen screw Internal M10X30MM DIN 912
INM03010287	Clamps support IM-5P (Z)	INM04080052	Allen screw Internal M6X10MM
INM03010292	IM-5P Working table	INM04080053	Allen screw Internal M6X16MM
INM03010297	Right stop washer IM-5P (Z)	INM04080054	Allen screw Internal M8X16MM
INM03010304	Base for the working table IM-5	INM04080066	Nut MA M5 ZINC
INM03010306	Tilting plate IM-5P	INM04080089	Allen screw Internal M6X10MM DIN 912
INM03010309	Tilting axle IM-5 (Z)	INM04080114	Allen screw Internal M5X35MM DIN 912
INM03010310	Washer IM-5 (Z)	INM04080143	Allen screw Internal M5X10MM DIN 912
INM03010318	Cylinder vertical clamps D50MM IM-5P	INM04080144	Rivet 3,2X10,2MM
INM03010319	Housing for the vertical clamps	INM04080149	Nut MA 16MM ZINC. DIN 934
INM03010333	Closet Stand IM-5	INM04080177	Nut MA 6MM ZINC.DIN 934
INM03010346	Right arm extension IM-5P	INM04080179	Nut MA 8MM ZINC
INM03010348	Nail Size Indicator IM-5 (Z)	INM04080200	Washer ¼" zinc steel
INM03010350	Left arm extension. IM-5P	INM04080201	Washer 5/16" zinc steel
INM03010352	Vertical bar IM-5 (Z)	INM04080219	Washer 3/8" zinc steel
INM03010354	Spring support IM-5 (Z)	INM04080250	Allen screw Internal M5X10MM DIN 7991
INM03010357	Stop for the nails strip pusher IM-5 (Z)	INM04080252	Phillips screw MT M3X8MM PAN ZINC
INM03010360	Cylinder IM-5P D63MM	INM04080256	Allen screw Internal M5X05MM
INM03010371	Nails guide complete with bushing IM-5	INM04080257	Allen screw Internal M6X45MM
INM03010372	Housing with bushing IM-5	INM04080259	Allen screw Internal M6X16MM
INM03010375	Cylinder for the front clamp D40MM IM-5P	INM04150020	Knob M8
INM03010378	Tracking screw IM-5 (Z)	INM04160053	Spring IM-5
INM03010380	Support for the cylinder IM-5 (Z)	INM04160056	Spring IM-5
INM03010382	Foot pedal guard IM-5P	INM04160059	Spring IM-5P
INM03010387	Longer support IM-5P with bushing and cilinder	INM04170070	Cotter 5X5X12MM T-A
INM03010388	Shorter support IM-5P	INM04170074	Flexible Ring 20MM
INM03010399	Left stop washer IM-5P (Z)	INM04190100	Table measure in inches (6") IM-5P
INM03010406	Shaft IM-5P COMPLETE	INM04190102	Table measure in millimeter 152MM IM-5P

INM03010411	Spring stop IM-5P (Z)	INM05040085	Operator's Manual IM-5P
INM03010426	Foot pedal F-5-1/4-B	INMP03010223	Complete nail pusher IM-5P
INM04050031	Caution label 28,0X72,0MM	INMP03010253	Nail strip pusher IM-5P
INM04050120	Serial number label	INMP03010291	Front clamp IM-5P COMPLETE
INM04050128	LATERAL label IM-5P closet stand	INMP03010299	Right moulding fence IM-5P COMPELTE
INM04050154	Main pressure regulator label IM-5P tilting stand	INMP03010313	Single hydraulic clamps IM-5P
INM04050155	Vertical clamps label IM-5P	7109	Pad IM-5P
INM04050156	Front clamp label IM-5P	INMP03010362	Left moulding fence IM-5P COMPLETE
INM04050157	Label IM-5P	INMP03010369	Nut IM-5P COMPLETE
INM04050158	Lateral Label IM-5P tilting stand	INMP03010373	Complete Nailing head IM-5P
INM04050159	Safety Label IM-5P	INMP03010390	Loaded cable IM-5P
INM04070005	Hose 6MM	INMP03010408	Washer IM-5P (Z)
INM04070006	Connection 1/8POLX6MM	INMP03010413	Kit gasket cylinder D50MM IM-5P
INM04070008	Hose 4MM	INMP03010414	Kit gasket cylinder D40MM IM-5P
INM04070027	Hose 8MM	INMP03010415	Kit gasket cylinder D63MM IM-5P
INM04070036	Connection 1/8POLX8MM	INMP03020045	Aluminum handle M6X19MM
INM04070038	Connection 1/4POLX8MM	INMP04070276	Kit hydraulic oil hose IM-5P
INM04070049	Connection 1/8POLX6MM	INMP04070279	Kit gasket air pressure regulator LR 1/8POL
INM04070051	Connection 1/8POLX8MM	INMP04070280	Kit gasket filter LF 1/4POL D MINI FESTO
INM04070052	Connection 1/4POLX4MM	INMP04070281	Kit gasket lubricator 1/4 D MINI FESTO
INM04070055	Connection 1/8POLX4MM	INMP04070282	Kit gasket foot pedal valve F 5-1/4 FESTO
INM04070067	Jointer 1/4"	INMP04070283	Kit gasket valve VL 5/2-1/8 FESTO
INM04070254	Connection L. 1/8-4	INMP04150003	Butterfly handle M6X20MM
INM04070286	Connection M5X4MM	INMP04150021	Locking handle with washer M10X25MM
INM04070287	Connection FEMEA 1/4POLX4MM	INMP04160014	Spring
INM04070288	Connection 1/8POLX8MM	INMP04160055	Locking pin IM-5P
INM04070289	Connection 4MM	INMP04160057	Spring IM-5


Kit reparo para Válvulas e Cilindros
Kit de reparo para Válvulas y cilindros
Valves and cylinder Kit repair

Cód.	Kit
INM04070293	INMP04070280
INM04070294	INMP04070281
INM03010426	INMP04070282
INM04070297	INMP04070279
INM04070298	INMP04070283




Kit reparo para Válvulas e Cilindros
 Kit de reparo para Válvulas y cilindros
 Valves and cylinder Kit repair


Cód.	Kit
INM03010360	INMP03010415



Kit reparo para Válvulas e Cilindros
Kit de reparo para Válvulas y cilindros
Valves and cylinder Kit repair

Cód.	Kit
INM03010318	INMP03010413
INM03010375	INMP03010414
INM04070297	INMP04070279





Mangueiras Pneumáticas Pneumatic hose Manguera Neumática	
INM04070005	Ø 6mm
INM04070008	Ø 4mm
INM04070027	Ø 8mm





TERMO DE GARANTIA

Os equipamentos da INMES Industrial Ltda, são garantidos por um período de 365 dias a partir da emissão da nota fiscal.

A obrigação da Assistência Técnica INMES, nos termos desta garantia, consiste no conserto do equipamento defeituoso.

Eventuais despesas de adaptação do local para a instalação dos equipamentos são de responsabilidade do cliente proprietário.

A garantia cobre qualquer tipo de defeito de fabricação, materiais, peças e a devida mão-de-obra para o conserto, quando devidamente comprovada pela INMES, ou um de seus Assistentes Técnicos Autorizados (ATI's).

Os equipamentos de fabricação de terceiros, que compõem os equipamentos INMES (Ex: motores, componentes pneumáticos, componentes elétricos, etc.) estão sujeitos as condições de garantia de seus respectivos fabricantes.

Não estão inclusas nesta garantia eventuais visitas solicitadas para limpeza ou reajuste do equipamento, devido ao desgaste decorrente do uso normal.

O cliente (comprador), será responsável pela locomoção do técnico até o local a ser efetuada a manutenção, alimentação e estadia se forem necessárias, bem como despesas com frete para encaminhamento e retorno do equipamento ao ATI's mais próximo, ou à fábrica.

Caso o cliente solicite alteração das características originais do equipamento, estas são de sua inteira responsabilidade.

Esta garantia será imediatamente cancelada se o equipamento sofrer acidente no decorrer do transporte, se for instalado em condições impróprias, como exposto a intempéries umidade, maresia, etc, se para o seu conserto forem utilizadas peças não originais INMES, ou se forem executados reparos por pessoas não autorizadas pela INMES Industrial Ltda.

No caso das máquinas de grampear, a garantia será cancelada no caso da utilização de grampos não originais INMES.

Esta garantia não cobre os problemas ocasionados por maus tratos, descuidos e mau uso do equipamento (operação do equipamento por pessoas não capacitadas para tal), em desacordo com o manual de instruções do mesmo.

Em nenhum caso a INMES Industrial Ltda, poderá ser responsabilizada por perda de produtividade, danos diretos ou indiretos, reclamações de terceiros, paralisações ou ainda quaisquer outras perdas ou despesas, incluindo lucros cessantes.

É imprescindível a apresentação do Termo de Garantia, devidamente preenchido para fazer uso da garantia, este sempre acompanhado da nota fiscal de compra do equipamento.

Ao solicitar o atendimento da garantia, tenha em mãos o Termo de Garantia.

Evite chamadas desnecessárias, caso ocorra algum problema com seu equipamento INMES, certifique-se do problema antes de chamar a assistência técnica.

Dados do Cliente e do Equipamento:

Nome/Razão Social do Cliente: _____

Endereço: _____

Equipamento/Modelo: _____ N de Série: _____

Nota Fiscal N : _____ Data: ____/____/____

Revendedor: _____

Local: _____ Data: ____/____/____

Relação Assistentes Autorizados
Atualização - 14/04/2008

Código	Nome do ATI	Endereço	Bairro	Cidade	Estado	CEP	Telefone	Contato	E-mail
2468	LEANDRO BEZERRA SILVA ME	RUA MANOEL DE FARIAS 118	CENTRO	BATALHA	AL	57420-000	(82) 35311-100	Leandro	leandrochorao@ig.com.br
2825	MARCELO CAMARA PONTES ME	RUA JOAQUIM NABUCO 1353	ALDEOTA	FORTALEZA	CE	60125-120	(85) 3212-1313	Alison	marcelo.moldurfort.com.br
1485	MOLDUSSOLY COM.DE ACESSÓRIOS E MAQ. LTDA	RUA JOAQUIM NABUCO, 363	NUCLEO COLONIAL	PINHAIS	PR	83321-120	(41) 3667 1111	Adieli	moldussolv@moldussolv.com.br
2376	COSCRATO & COSCRATO LTDA	RUA LOURENÇO DA VEIGA 600	JARDIM SABARA	LONDRINA	PR	86066-120	(43) 3028-9779	Denilson	irmac@onda.com.br
3236	ARTEMASSA PRODUTOS VIDRACARIA LTDA	AV COLOMBO, 8168	ZONA 06	MARINGÁ	PR	87080-190	(44) 3031-0991	Marcos	artemassandqa@hotmail.com
2862	GGE- GRAMPEADORES E GRAMPOS ESPECIAIS	RUA DA REGENERAÇÃO 331	BOM SUCESSO	RIO DE JANEIRO	RJ	21040-170	(21) 3977 5277	Francisco	gramampeadores@hotmail.com
2868	ARTE FUTURA IND. E COM. DE MOLDURAS LTDA	RUA JOSE DOMIGUES, 331	ENCANTADO	RIO DE JANEIRO	RJ	20756130	(21) 2595-3157	Demerval	afutura@terra.com.br
2995	TECNOAR COMÉRCIO E ASSISTENCIA LTDA	ROD.BR 116 KM 31,97	RIO BRANCO	NOVO HAMBURGO	RS	93336-290	(51) 3594 1060	Luiz	tecnoar@brturbo.com
3146	ELETRO ROCEL LTDA	RUA SÃO PAULO 898	BORGO	BENTO GONÇALVES	RS	95700-000	(54) 3454 1060	Ronaldo	rocel@brturbo.com
4879	BOSSARDI COMERCIO E IND. MECÂNICA LTDA	RS 115 Km 37 nr 150 Sala 01	VARZEA GRANDE	GRAMADO	RS	95670-000	(54) 3288 1776	Alfeu	bossardi@gramadosite.com.br
881	PEREIRA COM DE MOLDURAS LTDA	TRAV. JOSE CHAGAS SEIXAS, 97	PATRONATO	SANTA MARIA	RS	97020-450	(55) 3027-2602	João	pmoldura@terra.com.br
729	ELO MANUTENÇÃO E COM. DE MÁQUINAS LTDA	RUA VICE PREF. LUIZ CARLOS GARCIA 82	COSTA E SILVA	JOINVILLE	SC	89218-340	(47) 3435 5050	Pedro	elonaq@brturbo.com.br
3684	CSG AUTOMÇÃO INDUSTRIAL LTDA	RUA CARLOS PSCHIEDT 395	COLONIAL	SÃO BENTO DO SUL	SC	89290-000	(47) 3634 0372	Valdecir	csg.automacao@terra.com.br
3653	ELETRO PANSERA LTDA ME	AV. BRASÍLIA, 1887	CENTRO	PINHALZINHO	SC	89870-000	(49) 33366 1656	Gelton	eletrapansera@yahoo.com.br
5667	ELF AUTOMÇÃO INDUSTRIAL LTDA.	RUA PREFEITO DIB CHEREN, 2965	CAPOEIRAS	FLORIANÓPOLIS	SC	88090-001	(48) 3248 6240	Felippe	elf@interate.com.br
2701	J.F. MEDEIROS ME	RUA JOSÉ EMÍDIO DE FARIAS 2335	CENTRO	MIRASSOL	SP	15130-000	(17) 3242 7088	Kiko	ingrampeadores@terra.com.br
3576	EDSON SOUZA ALVES	RUA GONCALO BARROS, 665	CAPÃO REDONDO	SÃO PAULO	SP	05881-000	(11) 5874 5138	Edson	edsonsouzaalves@ig.com.br
5039	VERSATIL AUTOMÇÃO PNEUMÁTICA LTDA	AV. DUQUE DE CAXIAS 26-102	PARQUE SÃO JORGE	BAURU	SP	17030-520	(14) 3281-5999	Tiago	tiago.versatil@hotmail.com
5201	OLIVEIRA FERRAMENTAS SERVIÇOS E PEÇAS	AV. GOV. PEDRO DE TOLEDO, 1150	BOMFIM	CAMPINAS	SP	13070-150	(19) 3212 0446	Andréia	oliveiratercal@terra.com.br



INMES

Rod. SC 438 - Km 184
Caixa Postal 65 - CEP 88750-000
Braço do Norte - SC - Brasil
<http://www.inmes.com.br>
e-mail: vendas@inmes.com.br
SAC 0300 788 2022
+55 (48) 3658 3702