

4) To smooth and finish the corners, stroke the shank of a screwdriver from front to back.