



NO.	ORDER PART NAME	QTY.	NO.	ORDER PART NAME	QTY.
1	FLE12734 Handle (Right Hand)	1	14	FLE12713 Spring Stop Plate	1
2	FLE12735 Handle (Left Hand)	1	15	FLE12714 Main Spring	1
3	FLE12736 Trigger Assembly	1	16	FLE12715 Guide Pin	3
4	FLE12733 Magazine Assembly	1	17	FLE12716 Adjustable Knob	1
5	FLE12704 Follower Assembly	1	18	FLE12717 Square Nut	1
6	FLE12737 Channel	1	19	FLE12718 Washer	1
7	FLE12738 Push Plate	1	20	FLE12719 Follower Spring	1
8	FLE12707 Bumper	1	21	FLE12720 Cap	1
9	FLE12708 Stop Bar	1	22	FLE12721 Trigger Spring	1
10	FLE12709 Hammer	1	23	FLE12722 Pan Head Screw	2
11	FLE12710 Pawl	1	24	FLE12723 Plastite Screw	3
12	FLE12711 Pawl Pin	1	25	FLE12731 Magazine Screw	1
13	FLE12712 Torsion Spring	1	26	FLE12725 Magazine Nut	1