

Canvas Alignment Gauges



These instructions assume that the canvas print has been produced with a mirrored border for wrapping around a chosen stretcher frame.

First, select the correct gauge for the Lion stretcher bars you will be using.

- 7341 Standard height 20mm
- 7342 Premium height 25mm
- 7343 **Gallery** height 45mm
- 7344 XP Contract -height 39mm
- 1 Align the gauge to one corner of the image on canvas. The outer edge of the image is assumed to align with the bottom edges of the stretcher bar frame when wrapped. Hold firmly.
- 2 Place blade in notches 1 then 2 and cut to edge of canvas, as picture. Make guide cuts along cutting edges B and C. To finish, cut along full length of Cutting edge A. Repeat at other three corners.
- **3 & 4** Using straight edge, carefully align with guide cuts B and C and trim. Repeat at other three sides.
- 5 Now, turn the canvas face down and draw light pencil lines to position the stretcher frame. Using a straight edge carefully align it between cut notch marks and draw light lines at each corner.











